




# CHARNIÈRE INVISIBLE - AVEC AMORTISSEUR - 94° - EA 48 - SÉRIE 200

SALICE

**SALICE**








# MONTAGE EN DEMI APPLIQUE

# CHARNIÈRE INVISIBLE - AVEC AMORTISSEUR - 94° - EA 48 - SÉRIE 200


SALICE

**SALICE**

	T=1	T=2	T=3	T=4	T=5	T=6	T=7	T=8	T=9	T=10	T=11	T=12	T=13	T=14	T=15	T=16	T=17	T=18
10 - 10	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00
10 - 10	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00
10 - 10	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00
10 - 10	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00
10 - 10	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00
10 - 10	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00
10 - 10	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00



# MONTAGE EN APPLIQUE



# MONTAGE INTERIEUR